


NOTES: ● Parts marked by “NSP” are generally unavailable because they are not in our Master Spare Parts List.

● The ⚠ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

● Screws adjacent to ▼ mark on product are used for disassembly.

● For the applying amount of lubricants or glue, follow the instructions in this manual.
(In the case of no amount instructions, apply as you think it appropriate.)

9.1 PACKING SECTION



(1) PACKING SECTION PARTS LIST

Mark	No.	Description	Part No.	Mark	No.	Description	Part No.
⚠	1	USB Cable	DDE1128		9	Packing Case	See Contrast table (2)
	2	Power Cord	See Contrast table (2)		10	Mirror Mat (1200*1000)	DHL1169
	3	Operating Instructions (Quick Start Guide)	See Contrast table (2)	NSP	11	Polyethylene Bag	AHG7117
	4	Operating Instructions (Quick Start Guide)	See Contrast table (2)	NSP	12	Warranty	See Contrast table (2)
	5	Operating Instructions (Quick Start Guide)	See Contrast table (2)		13	•••••	
	6	Pad/F	DHA1914	NSP	14	Leaflet	DRM1420
	7	Pad/R	DHA1915	NSP	15	Leaflet	DRM1421
	8	•••••		NSP	16	Voucher Code Label Assy	DXA2342
				NSP	17	Voucher Code Label Assy	DXA2343

(2) CONTRAST TABLE

DDJ-SZ2/LSXXJ, UXJCB and XJCN are constructed the same except for the following:


Mark	No.	Symbol and Description	DDJ-SZ2/LSXXJ	DDJ-SZ2/UXJCB	DDJ-SZ2/XJCN
⚠	2	Power Cord	ADG1244	DDG1108	DDG1114
	3	Operating Instructions (Quick Start Guide) (En, Fr, De, It, Nl, Es, Pt, Ru)	DRH1410	Not used	Not used
	4	Operating Instructions (Quick Start Guide)(En)	Not used	DRH1411	Not used
	5	Operating Instructions (Quick Start Guide)(Zhcn)	Not used	Not used	DRH1413
	9	Packing Case	DHG3528	DHG3529	DHG3531
NSP	12	Warranty	DRY1270	Not used	Not used

9.2 TOP and CHASSIS SECTION

- A DDJ-SZ and DDJ-SZ2 are constructed the same except for the following:
For convenience of the system, the part names for the DDJ-SZ2 are simplified. The part names in parentheses are those for the DDJ-SZ.

Mark	No.	Symbol and Description	DDJ-SZ	DDJ-SZ2	Remarks
A	1	POWER SUPPLY Assy	DWR1463	Not used	
	1	SW POWER SUPPLY	Not used	DWR1566	
	2	AC Inlet/3P	DKP3954	DKP3985	
	4	Rotary SW Knob (C)	DAA1180	DAA1344	
	7	Knob (Rotary Knob (BN))	DAA1220	DAA1368	
B	8	Knob (Dial Knob)	DAA1259	DAA1371	
	12	Knob/SLD (Slider Knob 1)	DAC2684	DAC2935	
	14	Plate (Plate/MIX)	DAH2976	DAH3138	
	15	Plate (Plate/DEL)	DAH2982	DAH3139	
	16	Plate (Plate/DER)	DAH2983	DAH3140	
C	30	Knob (Knob/SLD)	DNK5981	DNK6682	
	31	Chassis	DNK6286	DNK6475	
	32	Shaft/EXT	DNK6305	DNK6410	
	38	DS Tape/ALR Escutcheon	DEH1050	DEH1079	
			Not used	DNK6473	No. 49
D		DS Tape	Not used	DEH1064	No. 50

TOP and CHASSIS SECTION



9.3 TERMINAL SECTION

DDJ-SZ and DDJ-SZ2 are constructed the same except for the following:
For convenience of the system, the part names for the DDJ-SZ2 are simplified. The part names in parentheses are those for the DDJ-SZ.


Mark	No.	Symbol and Description	DDJ-SZ	DDJ-SZ2	Remarks
	1	MAIN Assy	DWX3535	DWX3953	
	2	USBB Assy	DWX3555	DWX3752	
	3	AIJK Assy	DWX3536	DWX3768	
	4	AOJK Assy	DWX3537	DWX3769	
	5	HPJK Assy	DWX3538	DWX3770	
	6	CRFCV Assy	DWX3547	DWX3777	
	7	PSWB Assy	DWX3560	DWX3956	
	8	STRB Assy	DWX3585	DWX3962	

9.4 CONTROL PANEL SECTION

DDJ-SZ and DDJ-SZ2 are constructed the same except for the following:
For convenience of the system, the part names for the DDJ-SZ2 are simplified. The part names in parentheses are those for the DDJ-SZ.

Mark	No.	Symbol and Description	DDJ-SZ	DDJ-SZ2	Remarks
	1	DEUP Assy	DWX3548	DWX3961	
	2	KSWB Assy	DWX3549	DWX3958	
	3	SLDB Assy	DWX3550	DWX3959	
	4	DEUPR Assy	DWX3580	DWX3963	
	27	Sensor	DSX1124	DSX1135	
		SEQL Assy	Not used	DWX3763	No. 34
		QUAL Assy	Not used	DWX3764	No. 35
		QUAR Assy	Not used	DWX3765	No. 36
		SEQR Assy	Not used	DWX3766	No. 37
		Connector Assy	Not used	PF04PP-B17	No. 38
		Connector Assy	Not used	PF07PP-B17	No. 39
		Crimp Connector	Not used	PF08PP-B12	No. 40
		Crimp Connector	Not used	PF08PP-B17	No. 41
		Barrier	Not used	DEC3630	No. 42
		Stopper	Not used	DNK6532	No. 43
		Cable Tie	Not used	ZCA-SKB90BK	No. 44
		Screw	BPZ30P080FNI	BPZ30P100FTB	No. 45

A CONTROL PANEL SECTION




9.5 MIXER SECTION

DDJ-SZ and DDJ-SZ2 are constructed the same except for the following:
For convenience of the system, the part names for the DDJ-SZ2 are simplified. The part names in parentheses are those for the DDJ-SZ.

Mark	No.	Symbol and Desription	DDJ-SZ	DDJ-SZ2	Remarks
	1	MXRA Assy	DWX3543	DWX3954	
	2	MXRB Assy	DWX3544	DWX3964	
	3	FAD1 Assy	DWX3540	DWX3772	
	4	FAD2 Assy	DWX3541	DWX3773	
	5	FAD3 Assy	DWX3539	DWX3771	
	6	FAD4 Assy	DWX3542	DWX3774	
	16	Stay/MIX Spacer/CHF	DND1280 Not used	DND1285 DEC3558	No. 23

MIXER SECTION




9.6 PANEL and BUTTON SECTION

DDJ-SZ and DDJ-SZ2 are constructed the same except for the following:

For convenience of the system, the part names for the DDJ-SZ2 are simplified. The part names in parentheses are those for the DDJ-SZ.

Mark	No.	Symbol and Description	DDJ-SZ	DDJ-SZ2/LSYXJ	DDJ-SZ2/UXJCB	DDJ-SZ2/XJCN	Remarks
A	1	Control Panel	DNK6285	DNK6681	DNK6681	DNK6681	
	2	Sheet (Sheet/FR)	DAH2991	DAH3141	DAH3141	DAH3141	
	3	Sheet	DAH2992 (UXJCB)	DAH3142	DAH3143	DAH3145	
	9	Button (Button/FX1)	DAC2985	DAC3277	DAC3277	DAC3277	
	10	Button (Button/FX2)	DAC2986	DAC3278	DAC3278	DAC3278	
	11	Button (Button/CEN)	DAC2987	DAC3274	DAC3274	DAC3274	
	12	Button/ANY	DAC2988	Not used	Not used	Not used	
		Button	Not used	DAC3276	DAC3276	DAC3276	No. 26
		Button	Not used	DAC3279	DAC3279	DAC3279	No. 27
		Button	Not used	DAC3280	DAC3280	DAC3280	No. 28
		Button	Not used	DAC3281	DAC3281	DAC3281	No. 29
		Button	Not used	DAC3123	DAC3123	DAC3123	No. 30

PANEL and BUTTON SECTION PARTS



9.7 JOG DIAL SECTION

DDJ-SZ and DDJ-SZ2 are constructed the same except for the following:

For convenience of the system, the part names for the DDJ-SZ2 are simplified. The part names in parentheses are those for the DDJ-SZ.

Mark	No.	Symbol and Description	DDJ-SZ	DDJ-SZ2	Remarks
E	1	JFLL Assy	DWX3545	DWX3775	
	2	JFLR Assy	DWX3546	DWX3776	
	3	JLL1 Assy	DWX3556	DWX3965	
	4	JLL2 Assy	DWX3557	DWX3966	
	5	JLL3 Assy	DWX3558	DWX3967	
	6	JLL4 Assy	DWX3559	DWX3968	
	7	JLR1 Assy	DWX3561	DWX3969	
	8	JLR2 Assy	DWX3562	DWX3970	
	9	JLR3 Assy	DWX3563	DWX3971	
	10	JLR4 Assy	DWX3564	DWX3972	
F	11	JOGTL Assy	DWX3551	DWX3955	
	12	JOGTR Assy	DWX3565	DWX3957	
	13	JOGR Assy	DWX3552	DWX3960	