


## 9. EXPLODED VIEWS AND PARTS LIST

- NOTES:**
- Parts marked by “NSP” are generally unavailable because they are not in our Master Spare Parts List.
  - The  $\triangle$  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
  - Screws adjacent to  $\nabla$  mark on product are used for disassembly.
  - For the applying amount of lubricants or glue, follow the instructions in this manual.  
(In the case of no amount instructions, apply as you think it appropriate.)

### 9.1 PACKING SECTION



## (1) PACKING SECTION PARTS LIST


| <u>Mark No.</u> | <u>Description</u>                              | <u>Part No.</u>        | <u>Mark No.</u> | <u>Description</u>                            | <u>Part No.</u>        |
|-----------------|-------------------------------------------------|------------------------|-----------------|-----------------------------------------------|------------------------|
| A               | ⚠ 1 Power Cord                                  | See Contrast table (2) | 9               | Operating Instructions<br>(Quick Start Guide) | See Contrast table (2) |
|                 | ⚠ 2 Power Cord                                  | See Contrast table (2) | NSP 10          | Leaflet                                       | See Contrast table (2) |
|                 | 3 Audio Cable                                   | XDE3045                | NSP 11          | Polyethylene Bag                              | AHG7117                |
|                 | 4 LAN Cable                                     | DDE1141                | 12              | Packing Pad                                   | DHA1935                |
|                 | 5 Disc Force Eject Pin                          | DEX1024                |                 |                                               |                        |
|                 | 6 Operating Instructions<br>(Quick Start Guide) | See Contrast table (2) | 13              | Packing Pad                                   | DHA1936                |
|                 | 7 Operating Instructions<br>(Quick Start Guide) | See Contrast table (2) | 14              | Packing Case                                  | See Contrast table (2) |
|                 | 8 Operating Instructions<br>(Quick Start Guide) | See Contrast table (2) | 15              | Packing Sheet                                 | RHC1023                |
| B               |                                                 |                        | NSP 16          | Warranty                                      | See Contrast table (2) |
|                 |                                                 |                        | 17              | Caution Card SB                               | See Contrast table (2) |
|                 |                                                 |                        | NSP 18          | Label                                         | See Contrast table (2) |
|                 |                                                 |                        | NSP 19          | Name Label                                    | See Contrast table (2) |
|                 |                                                 |                        | NSP 20          | CCC S Label                                   | See Contrast table (2) |

## (2) CONTRAST TABLE

CDJ-2000NXS2/SYXJ, UXJCB, FLXJ and AXJ5 are constructed the same except for the following:

| Mark | No. | Symbol and Description                                                         | CDJ-2000NXS2<br>/SYXJ | CDJ-2000NXS2<br>/UXJCB | CDJ-2000NXS2<br>/FLXJ | CDJ-2000NXS2<br>/AXJ5 |
|------|-----|--------------------------------------------------------------------------------|-----------------------|------------------------|-----------------------|-----------------------|
|      | ⚠ 1 | Power Cord                                                                     | ADG1244               | DDG1108                | ADG1244               | DDG1114               |
|      | ⚠ 2 | Power Cord                                                                     | Not used              | Not used               | ADG1239               | Not used              |
|      | 6   | Operating Instructions (Quick Start Guide)<br>(En, Fr, De, It, Nl, Es, Pt, Ru) | DRH1322               | Not used               | Not used              | Not used              |
|      | 7   | Operating Instructions (Quick Start Guide)(En)                                 | Not used              | DRH1321                | Not used              | Not used              |
|      | 8   | Operating Instructions (Quick Start Guide)<br>(En, Es, Zhtw)                   | Not used              | Not used               | DRH1323               | Not used              |
|      | 9   | Operating Instructions (Quick Start Guide)(Zhcn)                               | Not used              | Not used               | Not used              | DRH1324               |
| NSP  | 10  | Leaflet                                                                        | DRH1275               | DRH1275                | DRH1275               | DRH1274               |
|      | 14  | Packing Case                                                                   | DHG3438               | DHG3440                | DHG3441               | DHG3443               |
| D    | NSP | 16                                                                             | Warranty              | ARY7158                | Not used              | Not used              |
|      | 17  | Caution Card SB                                                                | Not used              | Not used               | ARM7064               | Not used              |
| NSP  | 18  | Label                                                                          | Not used              | Not used               | Not used              | DRW2667               |
| NSP  | 19  | Name Label                                                                     | Not used              | Not used               | Not used              | DAL1335               |
| NSP  | 20  | CCC S Label                                                                    | Not used              | Not used               | Not used              | DRW2310               |

## 9.2 EXTERIOR SECTION





# EXTERIOR SECTION PARTS LIST

|   | <u>Mark No.</u> | <u>Description</u>     | <u>Part No.</u> |  | <u>Mark No.</u> | <u>Description</u>   | <u>Part No.</u> |
|---|-----------------|------------------------|-----------------|--|-----------------|----------------------|-----------------|
| A | 1               | MAIN Assy              | DWX3672         |  | 46              | Mecha Plate          | DNH2339         |
|   | 2               | SDCB Assy              | DWX3694         |  | 47              | Panel                | DAH3052         |
|   | 3               | USBA Assy              | DWX3695         |  | 48              | Cord With Plug       | DE007VE0        |
|   | 4               | SRVB Assy              | DWX3696         |  | 49              | Cord Clamper (Steel) | RNH-184         |
|   | ⚠               | 5 SW POWER SUPPLY Assy | DWR1548         |  | 50              | Cable Tie            | ZCA-SKB90BK     |
| B | ⚠               | 6 AC Inlet             | DKP3975         |  | 51              | Cushion              | DEC3680         |
|   |                 | 7 Shielded Conn-Cable  | DDA1053         |  | 52              | •••••                |                 |
|   |                 | 8 Shielded Conn-Cable  | DDA1052         |  | 53              | DM Screw (FTC)       | DBA1260         |
|   |                 | 9 FFC                  | DDD1703         |  | 54              | Screw                | BBZ30P060FTB    |
|   |                 | 10 FFC                 | DDD1706         |  | 55              | Screw                | BPZ30P080FNI    |
| C |                 | 11 Crimp Connector     | DDC1024         |  | 56              | Screw                | BPZ30P100FTC    |
|   |                 | 12 Connector Assy      | PF06PP-S10      |  | 57              | Screw                | IBZ30P100FTB    |
|   |                 | 13 Ferrite Core        | BTX1037         |  | 58              | Screw                | PMB30P080FTB    |
|   |                 | 14 Power Knob          | DAC2306         |  | 59              | Screw                | PMH30P080FTC    |
|   |                 | 15 SD Earth Spring     | DBK1357         |  | 60              | Screw                | PMH40P080FTC    |
| D |                 | 16 Silicon Rubber D5 L | DEB1456         |  | 61              | Screw                | PPZ30P080FTB    |
|   |                 | 17 Heat Cond Sheet     | DEB2018         |  |                 |                      |                 |
|   |                 | 18 Heat Cond Sheet     | DEB2019         |  |                 |                      |                 |
|   |                 | 19 Cushion             | DEB2024         |  |                 |                      |                 |
|   |                 | 20 Cushion             | DEB2030         |  |                 |                      |                 |
| E |                 | 21 Bracket/ACI         | DNH3020         |  |                 |                      |                 |
|   |                 | 22 Stay/KST            | DNH3021         |  |                 |                      |                 |
|   |                 | 23 Stay                | DNH3225         |  |                 |                      |                 |
|   |                 | 24 Stay                | DNH3226         |  |                 |                      |                 |
|   |                 | 25 Stay                | DNH3227         |  |                 |                      |                 |
| F |                 | 26 Shield Plate        | DNH3229         |  |                 |                      |                 |
|   |                 | 27 Plate               | DNH3230         |  |                 |                      |                 |
|   |                 | 28 Plate               | DNH3237         |  |                 |                      |                 |
|   |                 | 29 Heat Sink           | DNH3238         |  |                 |                      |                 |
|   |                 | 30 Servo Cover         | DNK5492         |  |                 |                      |                 |
|   | ⚠               | 31 Chassis             | DNK6500         |  |                 |                      |                 |
|   |                 | 32 Shaft               | DNK6501         |  |                 |                      |                 |
|   |                 | 33 Guide               | DNK6502         |  |                 |                      |                 |
|   |                 | 34 Insulator           | DXB2169         |  |                 |                      |                 |
|   |                 | 35 Sheet               | DEC3660         |  |                 |                      |                 |
|   |                 | 36 Heat Cond Sheet     | DEB2041         |  |                 |                      |                 |
|   |                 | 37 Heat Cond Sheet     | DEB2042         |  |                 |                      |                 |
|   |                 | 38 Cushion             | DEC3679         |  |                 |                      |                 |
|   |                 | 39 Gasket              | DEC3681         |  |                 |                      |                 |
|   |                 | 40 Cushion             | DEC3687         |  |                 |                      |                 |
|   |                 | 41 Cushion             | DEC3688         |  |                 |                      |                 |
|   |                 | 42 Gasket/JOG          | DEC3562         |  |                 |                      |                 |
|   |                 | 43 Damper              | CNV7618         |  |                 |                      |                 |
|   |                 | 44 Earth Spring        | DBH1398         |  |                 |                      |                 |
|   |                 | 45 Float Spring (G5)   | DBH1494         |  |                 |                      |                 |

5 6 7 8

# 9.3 CONTROL PANEL SECTION



A

B

C

D

E

F

# CONTROL PANEL SECTION PARTS LIST

|   | <u>Mark No.</u> | <u>Description</u>   | <u>Part No.</u> |   | <u>Mark No.</u> | <u>Description</u> | <u>Part No.</u> |
|---|-----------------|----------------------|-----------------|---|-----------------|--------------------|-----------------|
| A | 1               | PNLB Assy            | DWX3702         |   | 46              | DS ADH Sheet       | DEH1076         |
|   | 2               | KSWB Assy            | DWX3703         |   | 47              | DS ADH Sheet       | DEH1082         |
|   | 3               | EUPB Assy            | DWX3704         |   | 48              | Stay/VR            | DNF1894         |
|   | 4               | SLDB Assy            | DWX3705         |   | 49              | SD Card Door       | DNK5308         |
|   | 5               | HLED Assy            | DWX3700         |   | 50              | Ring Rens (PLAY)   | DNK5315         |
|   | 6               | FFC/4P               | DDD1641         |   | 51              | Tempo Lens         | DNK5316         |
|   | 7               | FFC                  | DDD1705         |   | 52              | Mode Lens          | DNK5317         |
|   | 8               | FFC                  | DDD1707         |   | 53              | Lever Cap          | DNK5344         |
|   | 9               | FFC                  | DDD1709         |   | 54              | Knob/SLD           | DNK5981         |
|   | 10              | FFC                  | DDD1711         |   | 55              | Lens/EUP           | DNK6040         |
| B | 11              | FFC                  | DDD1712         |   | 56              | Base               | DNK6470         |
|   | 12              | Panel                | DAH3051         |   | 57              | Lens               | DNK6491         |
|   | 13              | Plate                | DNH3223         |   | 58              | Lens               | DNK6492         |
|   | 14              | Sheet/FFC            | DEC3577         |   | 59              | Lens               | DNK6493         |
|   | 15              | Knob                 | DAA1303         | ⚠ | 60              | Control Panel      | DNK6494         |
|   | 16              | Button (LOOP)        | DAC2470         |   | 61              | Holder             | DNK6496         |
|   | 17              | Button (RELOOP)      | DAC2471         |   | 62              | Door               | DNK6497         |
|   | 18              | Button (4-BEAT LOOP) | DAC2472         |   | 63              | Holder             | DNK6498         |
|   | 19              | Button (JOG MODE)    | DAC2473         |   | 64              | Button             | DXB2170         |
|   | 20              | Button (TEMPO)       | DAC2474         |   | 65              | Sheet              | DEC3689         |
| C | 21              | Button (TEMPO REST)  | DAC2475         |   | 66              | Rivet (Plastic)    | RBM-003         |
|   | 22              | Button (EJECT)       | DAC2476         |   | 67              | •••••              |                 |
|   | 23              | Adjust Knob Black    | DAC2528         |   | 68              | •••••              |                 |
|   | 24              | Button/SLP           | DAC2865         |   | 69              | Flange Nut M9      | DBN1008         |
|   | 25              | Lever                | DAC3097         |   | 70              | Screw              | ABZ30P060FTC    |
|   | 26              | Button               | DAC3129         |   | 71              | Screw              | BBZ30P060FTB    |
|   | 27              | Button               | DAC3130         |   | 72              | Screw              | BPZ30P080FNI    |
|   | 28              | Button               | DAC3134         |   | 73              | Screw              | BPZ30P100FTC    |
|   | 29              | Button               | DAC3135         |   |                 |                    |                 |
|   | 30              | Button               | DAC3147         |   |                 |                    |                 |
| D | 31              | Button               | DAC3148         |   |                 |                    |                 |
|   | 32              | Button               | DAC3149         |   |                 |                    |                 |
|   | 33              | Slide Sheet 1C       | DAH2404         |   |                 |                    |                 |
|   | 34              | Lever Spring         | DBH1702         |   |                 |                    |                 |
|   | 35              | Spring               | DBH1717         |   |                 |                    |                 |
|   | 36              | Leaf Spring          | DBK1386         |   |                 |                    |                 |
|   | 37              | Gasket/JOG           | DEC3562         |   |                 |                    |                 |
|   | 38              | Sheet                | DEC3614         |   |                 |                    |                 |
|   | 39              | Brake                | DEC3634         |   |                 |                    |                 |
|   | 40              | DS ADH Sheet         | DEH1070         |   |                 |                    |                 |
| E | 41              | DS ADH Sheet         | DEH1071         |   |                 |                    |                 |
|   | 42              | DS ADH Sheet         | DEH1072         |   |                 |                    |                 |
|   | 43              | DS ADH Sheet         | DEH1073         |   |                 |                    |                 |
|   | 44              | DS ADH Sheet         | DEH1074         |   |                 |                    |                 |
|   | 45              | DS ADH Sheet         | DEH1075         |   |                 |                    |                 |
|   |                 |                      |                 |   |                 |                    |                 |
|   |                 |                      |                 |   |                 |                    |                 |
|   |                 |                      |                 |   |                 |                    |                 |
|   |                 |                      |                 |   |                 |                    |                 |
|   |                 |                      |                 |   |                 |                    |                 |
| F |                 |                      |                 |   |                 |                    |                 |
|   |                 |                      |                 |   |                 |                    |                 |
|   |                 |                      |                 |   |                 |                    |                 |
|   |                 |                      |                 |   |                 |                    |                 |
|   |                 |                      |                 |   |                 |                    |                 |

**16** Holder

The diagram shows the holder assembly with 16 screws highlighted in red circles. An inset shows a close-up of the holder being lubricated with oil (GYA1001) at two points, also highlighted in red circles.




# JOG DIAL SECTION PARTS LIST

| <u>Mark No.</u> | <u>Description</u>  | <u>Part No.</u> |
|-----------------|---------------------|-----------------|
| A               | 1 INDB Assy         | DWX3699         |
|                 | 2 JFLB Assy         | DWX3708         |
|                 | 3 JOGB Assy         | DWX3709         |
|                 | 4 Jog Panel         | DAH2609         |
|                 | 5 Jog Plate         | DAH2679         |
|                 | 6 Coil Spring/LD    | DBH1798         |
|                 | 7 SW Spring         | DBH1681         |
|                 | 8 SW Cushion HH48/2 | DEC2538         |
|                 | 9 Cushion/RNG       | DEC3466         |
|                 | 10 Washer           | DEC3137         |
| B               | 11 Link Plate       | DNH2848         |
|                 | 12 Jog B            | DNK4068         |
|                 | 13 SW Ring          | DNK5233         |
|                 | 14 Gear/LD          | DNK6145         |
|                 | 15 Smoother         | DNK5237         |
|                 | 16 Holder           | DNK6556         |
|                 | 17 Comp Plate       | DNK5243         |
|                 | 18 Adjust Plate     | DNK5300         |
|                 | 19 Cam Plate        | DNK5301         |
|                 | 20 Dial Gear        | DNK5302         |
| C               | 21 Link Gear A      | DNK5303         |
|                 | 22 Link Gear B      | DNK5304         |
|                 | 23 Rack Plate       | DNK5305         |
|                 | 24 Sheet SW         | DSX1078         |
|                 | 25 Jog Dial A Assy  | DXA2159         |
|                 | 26 Roller           | DXB2178         |
|                 | 27 Stay Assy/JOG    | DXB2133         |
|                 | 28 Encoder Spring   | DBH1710         |
|                 | 29 Plate            | DEC3700         |
|                 | 30 Gear/A           | DNK6143         |
| D               | 31 Gear/B           | DNK6144         |
|                 | 32 Leaf Spring/ADJ  | DBK1376         |
|                 | 33 •••••            |                 |
|                 | 34 •••••            |                 |
|                 | 35 •••••            |                 |
|                 | 36 •••••            |                 |
|                 | 37 Screw (FE)       | DBA1265         |
|                 | 38 Screw            | BPZ20P100FTC    |
|                 | 39 Screw            | BPZ30P080FNI    |
|                 | 40 Screw            | IPZ20P060FTC    |






- Bottom view



# DISPLAY SECTION PARTS LIST

| <u>Mark No.</u> | <u>Description</u> | <u>Part No.</u> |
|-----------------|--------------------|-----------------|
| A               | 1 LCDB Assy        | DWX3693         |
|                 | 2 TFT LCD          | CWX4352         |
|                 | 3 Touch Panel      | DSX1130         |
|                 | 4 Dial Knob        | DAA1246         |
|                 | 5 Button/MOD       | DAC2807         |
|                 | 6 Button           | DAC3113         |
|                 | 7 Button           | DAC3114         |
|                 | 8 Button           | DAC3115         |
|                 | 9 Button           | DAC3116         |
|                 | 10 Button          | DAC3117         |
| B               | 11 Button          | DAC3118         |
|                 | 12 Panel/TCP       | DAH3006         |
|                 | 13 Panel           | DAH3043         |
|                 | 14 Panel           | DAH3044         |
|                 | 15 Packing/LCD     | DEC3565         |
|                 | 16 Packing/L       | DEC3568         |
|                 | 17 Packing/S       | DEC3569         |
|                 | 18 Spacer/LCD      | DEC3571         |
|                 | 19 Light-D Sheet   | DEC3613         |
|                 | 20 Plate/GND       | DNH3173         |
| C               | 21 Shield Case     | DNH3220         |
|                 | 22 Stay            | DNH3221         |
|                 | ⚠ 23 Control Panel | DNK6465         |
|                 | 24 Cover           | DNK6466         |
|                 | 25 Holder          | DNK6467         |
|                 | 26 Lens            | DNK6468         |
|                 | 27 •••••           |                 |
|                 | 28 •••••           |                 |
|                 | 29 Screw           | BBZ26P060FTB    |
|                 | 30 Screw           | BPZ26P080FTC    |

## 9.6 SLOT IN MECHA SECTION



# SLOT IN MECHA SECTION PARTS LIST

| <u>Mark No.</u> | <u>Description</u>          | <u>Part No.</u>   |
|-----------------|-----------------------------|-------------------|
| A               | 1 SPCN Assy                 | DWX3698           |
|                 | 2 INSW Assy                 | DWX3697           |
|                 | 3 SLMB Assy                 | DWX3707           |
|                 | NSP 4 SLOTIN MECHA G11 Assy | DXA2163           |
|                 | 5 TM Assy 09SD-S            | DXX2697           |
| B               | 6 FFC                       | DDD1704           |
|                 | 7 FFC                       | DDD1713           |
|                 | 8 Connector Assy 2P         | DKP3769           |
|                 | 9 Connector Assy            | PF05PP-C25        |
|                 | 10 DC Motor Assy-S          | DXX2510           |
| C               | NSP 11 DC Motor S           | DXM1230           |
|                 | NSP 12 Worm Gear            | DNK3910           |
|                 | 13 Clamp Spring             | DBH1374           |
|                 | 14 Guide Spring             | DBH1375           |
|                 | 15 SW. Lever Spacer (PET)   | DEC2420           |
| D               | 16 Main Cam                 | DNK3407           |
|                 | 17 Disc Guide               | DNK3478           |
|                 | 18 Clamp Arm                | DNK3576           |
|                 | 19 Eject Lever              | DNK3684           |
|                 | 20 Lever AP                 | DNK3835           |
| E               | 21 Lever BP                 | DNK3836           |
|                 | 22 Loading Gear             | DNK3911           |
|                 | 23 Drive Gear               | DNK3912           |
|                 | 24 Clamper Assy             | DXA2043           |
|                 | 25 Loading Lever Assy       | DXB1880           |
| F               | 26 Loading Base Assy-S      | DEA1022           |
|                 | 27 Float Rubber D3          | DEB1404           |
|                 | 28 Spacer POR (T3)          | DEB1566           |
|                 | 29 Vessel Cushion A         | DEC2852           |
|                 | 30 Vessel Cushion B         | DEC2853           |
| G               | 31 Vessel Cushion C         | DEC2854           |
|                 | 32 Front Sheet              | DED1132           |
|                 | 33 Inside SW Base           | DNK4236           |
|                 | 34 Float Base G11 Assy      | DXB1793           |
|                 | 35 Binder                   | ZCA-SKB90BK       |
| H               | 36 Float Fastener           | DBA1286           |
|                 | 37 Screw                    | VBA1062           |
|                 | 38 Screw                    | IPZ20P060FTC      |
|                 | NSP 39 Lead Wire (JP1901)   | ZWNN1007G28-8-07A |
|                 | NSP 40 Lead Wire (JP1902)   | ZWNN1007G28-9-07A |